


# **ASTRA PREMIA P**

QUICK START GUIDE

### IMPORTANT: BEFORE YOU START

PLEASE CHARGE THE DEVICE FOR 1-2 HOURS BEFORE FIRST USE

### Layout



Voltage: 3.7V

Charging Voltage: 5V

Weight: 214 gm

Vibration: Dual Motors

Connectivity: Bluetooth/

Six Axis gyro, Touchpad and Speaker support

Battery: 3.7v 700mAH

OS: Playstation 4, Android, iOS

#### PAIRING INSTRUCTIONS

### Playstation® 4

Turn on your Playstation® 4 Console and connect the controller to the console as shown below



- B. Press the Home Button on your controller to power it on. The lights on your controller will flash white and then turn solid Blue (or Red depending on the channel)
- C. You can now remove the cable and use it in wireless mode

# Playstation® 5

Turn on your Playstation® 4 Console and connect the controller to the console as shown below



- B. Press the Home Button on your controller to power it on. The lights on your controller will flash white and then turn solid.
- C. You can now remove the cable and use it in wireless mode

Please note the the Premia P can be used to play PS4 games on a PS5. It does not support native PS5 games.

# Android/ Apple iPhone/ MacBook / iPad

- A. Press and Hold "Share" and "Home" button till the controller lights begin to flash.
- B. On your device, go to bluetooth settings and complete pairing.

PC

- Complete pairing as above.
- B. Windows PCs will acknowledge and recognize the controller as a DInput device unlike e.g. Mac OS. While Input mode will work for older games, Modern games require XInput mode.
- C. To use XInput mode on a PC, please install the required drivers available on our website (https://ninjadog.in ) under the support section.

#### ADDITIONAL TIPS

**Power**: You do not need to manually power off your controller.

Device will auto power off after about 30 seconds if no paired device is available. It will also power down after 10 minutes of non usage.

Charging: Slow Blink while charging, off when fully charged. It takes approximately 3 hours to fully charge the controller from a full discharge.

**Reset:** If your controller won't pair, won't respond, or is displaying a flashing light, You'll need to reset the controller. Use a SIM ejector or a thin paper clip to push the reset button.

In the unlikely event of any issues with pairing/usage,

Please reach out to us:

Email: support@ninjadog.in

Whatsapp: +91 93722 38794