

Vārna Pro Mechanical Wireless Keyboard

Thank you for choosing **Vārna Pro.** We are confident that it will serve you well for years to come.

The **Vārna Pro** is a compact 60% TKL keyboard with independent keycaps and switches that are hot swappable. With its elegant design, it should be equally at ease at your work desk or with your gaming rig.

As fellow geeks, we understand reading instruction manuals is tedious but please take a moment to read the *Getting started* section to ensure usage of the right connection protocol. This will enable your device to deliver an optimal user experience.

## GETTING STARTED



### **Powering On**

- Please use Alkaline or Ni-MH Batteries with your keyboard. Ordinary Zinc Carbon batteries can leak and damage your keyboard.
- 2. Insert 2 AAA Alkaline batteries in the battery compartment at the bottom of your keyboard.
- 3. Use the Power switch next to the battery compartment to switch on your keyboard .
- 4. The USB Adapter is stored next to the battery compartment
- 5. Low Battery Warning: When the battery voltage falls below 2.1V, the indicator light will flash to prompt battery replacement.

## **Pairing and Usage**

Fn + W: Bluetooth Device 1
 Fn + E: Bluetooth Device 2
 Fn + Q: 2.4Ghz USB adapter

## **Bluetooth Pairing**

- 1. Turn on the power switch and press Fn + W for 3 seconds. The W indicator light will flash to indicate Bluetooth pairing mode.
- 2. Use the Bluetooth Menu on your PC/tablet etc to scan and connect
- 3. A second Bluetooth device can be connected similarly using Fn + E

#### 2.4G USB Adapter

- 1. The included USB adapter is pre-Paired to your keyboard.
- If the USB adapter pairing is lost for any reason, you can Re Pair by holding the Fn + Q button till the Q LED flashes. Insert the USB adapter within 5 seconds to a PC USB port to complete the pairing.

#### **Switching between Devices**

 You can switch between your paired Bluetooth Devices and USB adapter with a short press of the keys. (e.g. Fn + W for Bluetooth 1)

Key Combinations		Key Combinations	
Fn + 1	F1	Fn + Number	F2, F3 etc
Fn + Esc	•	Fn + T	Multimedia
Fn + Shift + Esc	~	Fn + U / Y	Vol +/-
FN + Home	PrntSc	FN + I	Mute
Fn + Del	Ins	Fn + {	Play/Pause
Fn + PgDn	End	Fn + O	Stop Playback
Fn + PgUp	ScrlLk	Fn + P	Previous Track
FN + BackSp	Pause/Br	Fn + }	Next Track

# Support

In the unlikely event of any issues with pairing or usage, Please reach out to us:

Email: <a href="mailto:support@ninjadog.in">support@ninjadog.in</a>
Whatsapp: +91 93722 38794

